



## Low-Profile Aluminium Edging

### UPDATE

---

#### January 25<sup>th</sup>, 2023

Make sure that you have an up-to-date technical data sheet in hand by consulting our website: [techniseal.com](http://techniseal.com)

U.S.A. and Canada: dial 1 800 465-7325

Others: dial (514) 523-8324 (Canada)

### APPLICATIONS

---

- Perfect to define driveways, patios, alleys and walkways
- Works with natural stone, concrete paver, concrete slab, interlocking paver, porcelain tile.

### PROPERTIES

---

- Discreet - A low profile design that conceals the edging for a crisp installation.
- Weather-resistant - Won't deteriorate from exposure to the sun, frost, etc
- Flexible by hand - Easy to bend into any curve or create 90° angles without cutting
- Versatile - Ideal for the installation of pavers, flagstones, bluestones, granite, porcelain pavers and more.
- Each section is 8'4" long and 5/8" tall
- Made of 6063 aluminum alloy with T-5 hardness.
- Works on granular base as well as with Next Base™ panels.
- Convenient and easy to use.
- Made from 100% recycled material and recyclable.
- Material will not rust.

### DESCRIPTION

---

This discreet low-profile aluminium landscape edging is highly flexible and can be bent into any curve or used to create 90° without cutting. Very durable, it prevents pavers, natural stones, and porcelain tiles from shifting or moving.

### DIRECTIONS

---

#### BEFORE YOU BEGIN

Before proceeding with the installation, make sure you have an up-to-date technical data sheet in hand visiting [techniseal.com](http://techniseal.com).

### NECESSARY TOOLS

---

- Standard hammer or small mass
- Hacksaw
- Tin snips

## ANCHORING AND INSTALLATION

For patios and walkways : 1 spike every 18 inches (45 cm) and at each end.

For driveways : 1 spike every 12 inches (30 cm) and at each end.

1. Determine the amount of edging required by measuring the exterior perimeter of the project.
2. Edgings should be installed after the paver installation.
3. Lay edgings along the perimeter of the pattern with the tabs facing outwards.
4. Start anchoring the edgings using Techniseal Paving Edging Nails (70971150).
5. Edging can be easily bent by hand to form any curve or to create sharp angles.
6. Sections can be cut with a simple hacksaw or tin snips in order to achieve a clean cut.
7. Position nails at recommended spacing and drive nails into the ground using hammer or small mace.

## STORAGE

- The Low-Profile Aluminum Edgings are made of 100% recycled materials and are recyclable.

## PACKAGING

PRODUCT CODE	COLOR	SIZE	UNITS PER BOX	BOXES PER PALLET	UNITS PER PALLET
70973071	Aluminium	8'4" / 2.54 m	30	20	600

## WARNING

For more information and advice on the proper handling, storage, and disposal of this product, if applicable, please refer to the latest version of its Safety Data Sheet (SDS). This official document contains physical, ecological, and other important information pertaining to the safe usage of this product. Visit [www.techniseal.com](http://www.techniseal.com) or call 1-800-465-7325 to request or find an up-to-date version of this product's Safety Data Sheet (SDS).

**KEEP OUT OF REACH OF CHILDREN**

## TRANSPORT

For more information and advice on the proper handling and transportation of this product, if applicable, please refer to the latest version of its Safety Data Sheet (SDS). Visit [www.techniseal.com](http://www.techniseal.com) or call 1-800-465-7325 to request or find an up-to-date version of this product's Safety Data Sheet (SDS).